



# INSTRUCTION MANUAL

## POWER BLENDER

(BW02)





## POWER BLENDER (BW02)

230V, 50HZ, 400W, 570ML & 240ML  
POLYCARBONATE JARS, SIPPER CAP

HOUSEHOLD USE ONLY

## IDENTIFICATION OF PARTS




## USER INSTRUCTIONS

Please read these instructions carefully before using the product and retain them for future reference.





- Ensure that the appliance's voltage matches the local power supply before connecting it.
- Do not operate the appliance if the power cord, plug, or any other part is damaged.
- If the power cord is damaged, it must be replaced by the manufacturer, an authorized service agent, or a qualified professional to avoid hazards.
- Never immerse the motor unit in water or any other liquid, nor should it be rinsed under running water. Use only a damp cloth to clean the motor unit.
- This appliance is not suitable for children, **without parental supervision.**
- Cut larger ingredients into pieces of around 2 cm before blending.
- If the blade unit gets stuck, disconnect the motor and remove the lid to clear the blockage using a spatula.
- Handle the blades with care to avoid injury as they are very sharp.
- Wait for the blades to stop completely before removing the lid.
- Do not operate the appliance without ingredients.
- This appliance is for household use only.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person for their safety.
- If the power cable or the plug is damaged, do not use the appliance. To avoid any risk, these must be replaced by the manufacturer.




## ACCESSORIES







## HOW TO USE

			
<p>1 Place the blending jar on a flat surface. Open the jar, fill it with your favorite ingredients, all the ingredient must be filled below the jar max level mark.</p>	<p>2 Fasten the blade base on the open end of the blending jar. Please use the blade base for Blending Jar (with cross type blade) ONLY.</p>	<p>3 Turn the jar upside down. Put the blending jar and blade base together on the blender base. Ensure the three micro switch block in right position.</p>	<p>4 Press the middle button to start the machine. Release your finger the machine will stop.</p>

		
<p>5 Unlock the blending jar from the base.</p>	<p>6 Flip the jar, set it down, and remove the blade base.</p>	<p>7 Put the sipper lid on.</p>

## HOW TO USE

			
<p>1 Open the grinder jar. Put in the dry ingredient only, wet food are not allow for grind.</p>	<p>2 Seal with the grinder blade.(The single type blade ONLY)</p>	<p>3 Turn the grinder jar upside down, put it in the blender base, ensure the micro switch block in right position.</p>	<p>4 Press the middle button to start the machine, release your finger the machine will stop.</p>

**NOTE :** Operate no longer than 1 minute.

## USAGE GUIDELINES

- Only the jar, blade base and sipper lid are dishwasher safe; other parts are not.
- For best results, the blender can crush ice with its well-designed blades, but don't **overfill** the jar with ice.
- When blending, always include water or another liquid. Cut fruits into small pieces beforehand.

## **NEW FEATURE**

### **Temperature Overload Protector (TOP)**

- Use the appliance for a maximum of 1 minute continuously, then allow a 1-minute break to prevent overheating.
- If used beyond the recommended time, the Temperature Overload Protector (TOP) will automatically shut off the motor to prevent overheating.
- The motor will resume normal operation after a cooldown period of 20–30 minutes.

## **CLEANING**

Do not use abrasives, scourers, alcohol, etc. to clean the appliance. Never immerse the blender base (motor unit) in water or other liquid and never clean it in the dishwasher.

1. Unplug the appliance and disassemble it. For extra thorough cleaning, you can also remove the sealing ring and non-slip ring.
2. Clean the bottle, the cup, the lid, the blade unit, the sealing ring, and the non-slip ring in warm water with some washing-up liquid.
3. Clean the motor unit with a moist cloth.

## **ENVIRONMENT**

Do not throw the appliance away with normal household waste at the end of its life but hand it in at an official collection point for recycling. By doing this you will help to preserve the environment.

## **PLEASE NOTE**

- Do not switch on the appliance while accessories are stored inside the jar.
- Never store cutting and slicing blades inside the jar.
- Incorrect operation can seriously damage the product.

## **TROUBLESHOOTING**

If the appliance fails to work, check the following:

- Ensure it is properly connected to a power source.
- Confirm that the jar base cover is securely locked onto the blender base.
- Make sure the locking mechanisms are properly engaged.
- If the appliance still does not function, contact an authorized service center or the manufacturer for assistance.

WARRANTY REGISTRATION

Product Name:

Power Blender

Model Number:

BW02

Product Serial No. :

TO REGISTER YOUR  
**WARRANTY**



SCAN HERE







# Follow us on:

@blendwelindia  www.blendwel.com

Taatva Appliances, No.830, 5th A Cross, 9th  
Main, HRBR Layout, Kalyan Nagar, Bangalore  
- 560043, Karnataka, India

TO REGISTER YOUR  
**WARRANTY**

