



INSTRUCTION MANUAL

PORTABLE BLENDER

(BW03)





PORTABLE BLENDER (BW03)

400ML, 7.4V, 126W, 15,000 - 16,000 RPM

PORTABLE POWER IN YOUR HANDS

IDENTIFICATION OF PARTS



USER INSTRUCTIONS

To ensure safe and proper use of this blender, carefully read the instructions below and keep this manual for future reference. Read this manual before using the blender.

- This blender is compatible with **USB-B connector** chargers and power banks.
- Do not use the blender for purposes other than those intended.
- This appliance is not suitable for children, **without parental supervision**.
- If the USB cable or plug is damaged, stop using the blender immediately.
- Avoid contact between the USB cable and sharp or high-temperature surfaces.
- Do not touch the plug with wet hands. Always unplug by holding the plug itself rather than pulling on the cable.
- Never immerse the blender in water or any other liquid.
- Do not clean with boiling water.
- Do not disassemble the blender. If malfunction occurs, contact an authorized service centre.
- Ensure the blender is correctly assembled before turning it on.
- The blade is sharp—handle with care when installing, removing, or cleaning it.

Warnings:

- Failure to follow operating instructions may result in injury or product damage.
- Incorrect usage may cause harm to people, property, or the appliance itself.
- Never open the lid while the blender is operating.
- Avoid touching rotating parts at all times.
- If the blender becomes jammed, turn off the power and remove any obstructions before restarting.
- Do not exceed 2/3 of the bottle's capacity when filling with food or liquid.
- This blender cannot chop meat, nuts, or beans directly, as this may damage the motor and reduce the appliance's lifespan.



"-" : Ready to use


"o" : Power cut off

After completing the blending or cleaning process, switch the bottom safety switch to the "O" position. Before the next use, switch the safety switch to the "—" position.

PRODUCT SPECIFICATIONS

Specification	Details
Model	BW03
Capacity	400ml
Power	126W
Motor	7.4V
Rated Voltage	7.4V
Motor Speed	15,000 - 16,000 RPM
Input Power	5V, 2A

DESCRIPTION OF PARTS



CHARGE


Battery Capacity: 2600mAh × 2

Compatible with USB adapters ($\leq 2A$), power banks, and car chargers.


Charging Process:

- Insert the USB cable into the socket at the base of the blender.
- Connect the other end to a USB power source.
- Red light = Charging. White light = Fully charged.

Do not operate the blender while charging.



HOW TO USE



After the blending process, open the lid, and pour the blended drink into a glass. Rinse the jar immediately after use for easy cleaning.

INDICATOR LIGHT INSTRUCTIONS

- Starting the Blender: Double-click the power button. The blender will run for 45 seconds before stopping automatically. A white indicator light will remain on while the blender is running.
- Charging: When connected to a power source via USB:
 - Red light on: Charging in progress.
 - White light on: Fully charged.
- Incorrect Assembly: If the bottle is not attached properly, the red light will flash five times to indicate an error.
- Operation Blockage: If the motor stops due to jammed food, the red and white lights will flash alternately for ten times.
- Low Battery Warning:
 - When the battery is nearly depleted, the red light will remain on for five seconds.
 - If water is added below the blades, the machine will stop for protection after five seconds, and the red light will flash three times.

OPERATING INSTRUCTIONS

Blending Process:

- Cut fruits into small pieces (1.5cm - 2cm). Remove seeds and peels.
- Add fruits and liquid (water or milk) into the bottle.
- Double-click the power button to start blending.
- The blender will stop automatically after 45 seconds.

Assembly Instructions:

- Ensure the waterproof rings are properly positioned on the lid and blade base.

- Secure the bottle to the blade base by twisting clockwise until fully locked.
- Press the power button once—if the indicator light turns white, the assembly is correct.

CLEANING INSTRUCTION

- Detach the bottle from the base.
- Rinse the bottle and lid with water.
- Wipe the blender body with a damp cloth—avoid water entering the USB socket or power switch.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Blender does not start (red light blinks)	Bottle not screwed on properly	Securely attach the bottle and try again
Blender does not work (red light stays on for 5 sec)	Battery is empty	Charge the blender before use
Blender stops automatically	Overloaded or reached 45-second limit	Restart the blender after adjusting contents
Red & white lights flash alternately for 10 sec	Motor is jammed	Remove obstructions and restart
Leakage	Silicone ring not properly installed	Reinstall the silicone ring correctly
Smoke or overheating	Continuous use for too long	Let the blender cool for 30-60 minutes before restarting

WARRANTY REGISTRATION

Product Name:

Portable Blender

Model Number:

BW03

Product Serial No. :



**TO REGISTER YOUR
WARRANTY**



SCAN HERE



Follow US on:

@blendwelindia www.blendwel.com

Taatva Appliances, No.830, 5th A Cross, 9th
Main, HRBR Layout, Kalyan Nagar, Bangalore
- 560043, Karnataka, India

TO REGISTER YOUR
WARRANTY

